




SOLUTIONS FOR THE GLASS INDUSTRY

STIRRER MECHANISM





The purpose of the Stirring Mechanisms is to homogenize the glass in the forehearth.

The main applications are:

- Removal of cat scratches
- Removal of cords
- Glass blending in colouring forehearths

Taking into account the severe working conditions due to the high working temperatures, special attention has been paid to select the appropriate materials, both for the steel supporting frame and for the moving parts which are subject to wear, in order to improve their reliability and to reduce as much as possible the maintenance operations.

Generally a stirrer mechanism comprises the following:


- A steel support frame
- A manual or automatic lifting system to remove the stirring unit
- Stirrers (paddle type or screw type)
- Control system (either a central control cabinet or a local control panel)

Glass Service produces the following stirrer systems:

- Standard flag-type stirring machine
- X-Y stirring machine




FLAG-TYPE STIRRER MECHANISM



The stirring machine consist of:

- Steel vertical support column manufactured from large diameter steel tube
- Stirring mechanism that can be moved vertically on the above column by means of a manually operated rack and pinion system (optionally a motor can be installed)
- Drive system comprising an electric motor and gearbox with manual speed control
- Drive system with chain, tensioner and pinion
- Screw spindles provided with special high temperature graphite bearings
- Quick type coupling system for refractory screws or paddles
- Compressed air system with filter, pressure governor and accessories for bearing cooling and lubrication
- Heat shield
- Control box with drive inverter, emergency stop button and start/stop






A series of flag-type stirring machines

TECHNICAL CHARACTERISTICS


Vertical height	Approx. 2.275mm - customizable
Vertical stroke of stirring mechanism	Approx. 950mm - customizable
Distance from center forehearth to support column	customized
N° of rotors	1 to 5
Max. weight of stirrers	120 kg each
Stirrer revolution speed (manual adjustment) - screw type	4.8 - 26 rpm
Stirrer revolution speed (manual adjustment) - paddle type	1.3 - 12,6 rpm
Installed power	0.75 kW
Power supply	380 V 3 ph - 50 Hz / 440V 60 Hz

MAINTENANCE AND REPLACEMENT OF STIRRERS


The maintenance and the replacement of the paddles/screws is easily carried out.
The operation sequence for this is as follows:




Step 1 - Working position



Step 2



Step 3




Step 4 - Maintenance position

- Strong steel structure
- Manual or motorized vertical movement
- Quick release coupling for the refractory screws or paddles
- Bearing lubrication and cooling system
- Up to 5 rotors can be installed
- Easy changing of the paddles/screws
- Easy maintenance



X-Y STIRRER MECHANISM



Glass Service has developed a stirring mechanism with two movements on both the X and Y axes that greatly reduces the space required for the installation and simplifies any maintenance operation.

This machine is a vertical structure attached to the forehearth steel frame.

An electric motor drives the chuck support arm up and down the structure.

This Y movement is achieved by moving the supporting arm on two parallel reinforced rails with special bearings and reinforced wheels.

The motor and gearbox are located on top of the structure with a chain directly coupled to the chuck holder arm. In the unlikely event of chain breakage the arm cannot fall down due to the special design of the rails.


The chuck support arm can easily slide towards the side of the forehearth on a horizontal arm. This movement is again operated on two parallel and reinforced rails with special bearings and reinforced wheels whilst power transmission is achieved through a rack and pinion. Each spindle turns on large graphite ball bearings

Thanks to this innovation the following features can be achieved:

- Minimum installation space
- Any maintenance operation, both on paddles or motor, is simpler and performed away from the hottest area of the forehearth
- The re-positioning of the spindles over the forehearth is very simple and precise.

TECHNICAL CHARACTERISTICS

General dimensions	according forehearth dimensions
N° of rotors	1 to 5
Rotors interaxis	tailored
Max. weight of each stirrer	60 kg
Stirrer revolution speed (manual adjustment) - screw type	4.8 -26 rpm
Stirrer revolution speed (manual adjustment) - paddle type	1.3 - 12.6 rpm
Installed power	0.75 kW
Installed power for spindle arm raising mechanism	0.18 kW
Power Supply	various



the possibility to rotate in two directions, so that, according to the installation the system can be configured as following:

- All rotors with the same rotation sense
- Each rotor rotating in opposite rotation

Optionally an inverter can be used to control the rotation speed.

Each moving part of the machine is fitted with steel guards for safety purposes as well as to protect the mechanisms from dust.



The drive assembly is also cooled and lubricated by means of compressed air.

The machine can support any type of rotor currently available on the market.

The chuck and rotor coupling system is a quick release model.

On the top of the chuck holder arm the rotors power transmission group is located.


Rotors are driven by a motor plus its gearbox, allowing a perfect control of the rotation speed. This group is designed to allow, for each rotor,




MAINTENANCE AND REPLACEMENT OF STIRRERS

The maintenance and replacement of the paddles/screws is easily carried out and requires very little space at the side of the forehearth.


The operation sequence for this is as follows:




Step 1 - Working position



Step 2



Step 3



Step 4 - Maintenance position

- Minimal installation spaces
- Maintenance operation simplified
- Quick type coupling system for refractory screws or paddles
- Bearing cooled and lubricated
- Up to 5 rotors installable
- Minimum space required for stirrer replacement




ROTORS TYPE

ROTORS TYPE SELECTION


Two types of rotors can be used, these are:

- Paddle type
- Screw type

Glass Service will suggest the correct type of rotor according to the customer requirements.




Paddle rotors



Screw rotors

Below are some types of rotors that **Glass Service** can supply according to the requirements of the customer:




and many others...

ROTOR POSITIONING

Depending on the forehearth width, type of glass, type of colouring, the available space at the sides of the forehearth etc., we will offer the best solution for the installation of the stirring unit.

Below are simple sketches of a possible installation:



CONTROL CABINET



Glass Service can provide a compact control cabinet including:

- Main power on/off
- Motor protection control
- Start / stop push buttons for spindle rotation
- Emergency stop button
- Red flashing light for alarms

As an option we can provide remote control cabinet with:

- Inverter control for spindles rotation
- Speed control device for chucks rotation (AUTO / MAN, INC/DEC speed, integrated display). A spindle speed control using an inverter integrated into the control cabinet will allow the system speed to be controlled remotely in the optimal range (i.e. 1.4 to 13 rpm for paddles) both from a remote DCS (with a 4-20 mA signal) as well as directly from the stirrer cabinet, setting a value between 0 and 100%.



CUSTOMERS WORLD WIDE

STM-17-01-E



turn key project

batch plants

furnaces:

recuperative

regenerative

gas fired

oil fired

oxy-fuel fired

mixed fuel

electric

forehearth:

colouring forehearth

combustion systems

day tanks

mini melters

boosters

bubblers

metallic recuperators

batch chargers

stirring machines

glass level controls

frit dosing and transport

control cabinets

SCADA and DCS

cooling systems

robotics

gathering - 4 or 5 axis

services:

installation and supervision

commissioning

training

preheating

technology transfer

assistance

laboratory and analysis

refractory consulting

project financing



GLASS SERVICE s.r.l.

via Cascina Lari 56028 San Miniato (PI) ITALY

tel. +39 0571 4442

www.glassservice.it